


Flip Video Camera Quick Start Guide

<http://www.theflip.com/>




Flip Camera Features

Front



Back



Connecting to a Computer


1. Make sure the Flip is off.
2. On the side of the Flip (left side when viewed from the back, right side when viewed from the front), slide the latch down to release the USB connector arm.
3. Insert the connector into a USB port on your computer.



Note: It is recommended you use a USB extension cable if there is not enough space for your camera.

Starting the Flip Video Program

1. Follow the instructions under "Connecting to a Computer."
2. To start the program:
Mac: Double click the **FLIPVIDEO** icon on your desktop, and double click **Start Flipshare**.
PC: Click **View your Flip Camcorder Videos using the program on device** in the pop-up dialog box, and click **OK**.
3. The Flip Video Program will appear with your recorded videos previewed in the right screen.




Note: The program runs directly from your Flip camera, it can only be used when the Flip is connected to your computer.

For assistance, go to http://www.theflip.com/support_home.shtml

Transferring/Saving Videos


1. With the Flip connected and the Flip Video Program running, click on the video you want to save.
2. Click the **Save to Computer** icon, or **File > Save to computer**.
3. A dialog box will appear showing where the video will be saved, and asking if you want to delete it from the Flip. Select your options and click **Yes**.
4. The saved video will appear in the left window under "Computer."




Note: All videos will also be stored on your Flip video camera until you delete them.

Organizing Your Flip Video Library

1. Make sure your Flip is connected to the computer and the Flip Video Program is running.
2. In the left window area under "Computer," click the **Add New File** icon, or click **File > Add New Folder** at the top of the screen.
3. An **Untitled Folder** will appear under "Computer."
4. Double click this folder (Mac) or right click and select "rename"(PC) to highlight the text, type in a new name for the folder and hit enter on the keyboard.




The new folder name will appear under "Computer."



Sharing Your Videos

1. Make sure your Flip is connected to the computer and the Flip Video Program is running.
2. Click on the video you would like to share.
3. At the top of the screen, click on **File > Export to...**, and click **Export**.
4. In the finder window that appears, select the **Desktop** on your computer, and click **Choose**.
5. A copy of your video will be saved on your Desktop as a .AVI file.



You can then email your video or upload it to the web on a site such as YouTube or TeacherTube.

Disconnecting the Flip

1. Quit the Flip Video Program by clicking on **Flipshare > Quit Flipshare** at the top of the screen.
2. To safely eject the Flip video camera:

Mac: In the finder window, click the eject button icon or drag the FLIPVIDEO icon on your desktop to the trash.



PC: Click the **Safely Remove Hardware** icon at the bottom right of the Windows taskbar, and in the pop-up box that appears click **Safely remove USB Mass Storage Device**.



A pop-up window will appear confirming it is safe to remove the device.

3. You can now remove the Flip video camera from your computer.

Flip Video Information and Support

To learn more about how to use the Flip camera and its additional features, visit the Flip Video Support page at http://www.theflip.com/support_home.shtml, where you can search through their online knowledgebase, submit a question to their technical support group, and get updates for your Flip camera software.

Additional help and resources can be found at:

- Information on the Flipshare Program: http://www.theflip.com/products_flip_flipshare.shtml.
- Specifications for the Flip camera: <http://www.theflip.com/products.shtml>.
- Flip Video Q & A section: http://www.theflip.com/support_video.shtml.

For assistance, go to http://www.theflip.com/support_home.shtml