

Flip SlideHD Camera Quick Start Guide


<http://www.theflip.com/>

flip
video™




Flip SlideHD Camera Features

Front



Back



Connecting to a Computer


1. Make sure the Flip is off.
2. On the side of the Flip (left side when viewed from the back, right side when viewed from the front), slide the white latch down to release the USB connector arm.
3. Insert the connector into a USB port on your computer (keeping the camera on a flat surface).



Note: It is recommended you use a USB extension cable if there is not enough space for your camera.

Starting the Flip Video Program

1. Follow the instructions under "Connecting to a Computer."
2. If the program does not start automatically:
Mac: Double click the **FLIPVIDEO** icon on your desktop, and double click **Start Flipshare**.
PC: Click **View your Flip Camcorder Videos using the program on device** in the pop-up dialog box, and click **OK**.
3. The Flip Video Program will appear with your recorded videos previewed in the right screen.




For assistance, go to <http://www.theflip.com/en-us/support/>


Saving Videos to Your Computer

To save a video to your computer in order to edit it in a program such as iMovie or Windows Movie Maker:

1. Make sure your Flip camera is connected to the computer and the Flip Video Program is running.
2. Click on **FlipShare > Preferences**, and select **Library** from the pop-up window options.



3. Click the **Change Location** button to choose where your videos will be saved on your computer.




4. Click **OK** to restart the Flipshare Program


Note: Follow the "Starting the Flip Video Program" directions if the program does not automatically restart.

5. Click on the video you want to save.

6. Click the **Save to Computer** icon, or **File > Save to computer**.



7. A dialog box will appear showing where the video will be saved. Select any additional options and click **Yes**.



8. The video will be saved on your computer.

You can now access the video directly on your computer without having to use the Flipshare Video Program.

Note: All videos will also be stored on your Flip video camera until you delete them.

Exporting Your Videos

1. Make sure your Flip is connected to the computer and the Flip Video Program is running.

2. Click on the video you would like to share.

3. At the top of the screen, click on **File > Export to...**, and click **Export**.



4. In the finder window that appears, select the **Desktop** on your computer, and click **Choose**.

5. A copy of your video will be saved on your Desktop as a .MP4 file.



You can then email your video or upload it to the web on a site such as YouTube or Vimeo.

Disconnecting the Flip SlideHD

1. Quit the Flip Video Program by clicking on **Flipshare > Quit Flipshare** at the top of the screen.

2. To safely eject the Flip video camera:

Mac: In the finder window, click the eject button icon or drag the FLIPVIDEO icon on your desktop to the trash.



PC: Click the **Safely Remove Hardware** icon at the bottom right of the Windows taskbar, and in the pop-up box that appears click **Safely remove USB Mass Storage Device**.



A pop-up window will appear confirming it is safe to remove the device.

3. You can now remove the Flip video camera from your computer.

Flip SlideHD Video Information and Support

To learn more about how to use the Flip camera and its additional features, visit the Flip Video Support page at <http://www.theflip.com/en-us/support/>, where you can search through their online knowledgebase, submit a question to their technical support group, and get updates for your Flip camera software.

Additional help and resources can be found at:

- Information on the Flipshare Program: <http://www.theflip.com/en-us/Products/flipshare.aspx>.
- Specifications for the Flip SlideHD camera: <http://www.theflip.com/en-us/Products/slidehd.aspx>.
- Flip Video Q & A section: http://www.theflip.com/support_video.shtml.

For assistance, go to <http://www.theflip.com/en-us/support/>